

The Configuration Sheet

For basic programming instructions
look under the CLAW or visit

www.claw.com.au



Diagram of the CLAW device with button locations marked. Surrounding the device are five configuration boxes:

- Button #9** (left): Keys: Actions:
- Button #8** (top left): Keys: Actions:
- Button #7** (top center): Keys: Actions:
- Button #6** (top right): Keys: Actions:
- Button #5** (right): Keys: Actions:

Default Button Configuration

Memory #1		Memory #2	
Button 1	a	Button 1	1claw
Button 2	b	Button 2	2
Button 3	c	Button 3	3
Button 4	d	Button 4	4
Button 5	e	Button 5	5
Button 6	f	Button 6	6
Button 7	g	Button 7	7
Button 8	h	Button 8	8
Button 9	i	Button 9	9

Diagram of the CLAW device showing button locations. Surrounding the device are four configuration boxes:

- Button #1** (top left): Keys: Actions:
- Button #3** (top right): Keys: Actions:
- Button #2** (bottom left): Keys: Actions:
- Button #4** (bottom right): Keys: Actions:

